

## INSTALATION AND TRIMMING GUIDE

### Persihing, YS+, Purple Ice, Prototype Model, TOUR AD (45.0" - 47.0")

	Products	Through Bore	Blind Bore	Standard Bore
Driver	Pershing 55, 65, 75	0.0"	0.5"	1.0"
	YS-5+, YS-6+, YS-7+			
	YSQ 55, 65			
	Quattro Tech Md			
	Pershing 45	Insert 2.0" only	Butt Trim Only	
	Quattro Tech, Tour AD I-65, W60, W70	Insert 2.0" only	0.0"	0.0"
#3 Wood	Pershing 55, 65, 75	0.5"	1.0"	1.5"
	YS-5+, YS-6+, YS-7+			
	YSQ 55, 65			
	Quattro Tech Md			
	Pershing 45	Insert 2.0" only	Butt Trim Only	
	Quattro Tech, Tour AD I-65, W60, W70	Insert 2.0" only	0.5"	0.5"
#5 Wood	Pershing 55, 65, 75	1.0"	1.5"	2.0"
	YS-5+, YS-6+, YS-7+			
	YSQ 55, 65			
	Quattro Tech Md			
	Pershing 45	Insert 2.0" only	Butt Trim Only	
	Quattro Tech, Tour AD I-65, W60, W70	Insert 2.0" only	0.5"	1.0"

### YS Hybrid+, TOUR AD UT - 55, 65, 85, 95 Hybrid (42.0"-44.0")

	Products	Standard Bore				
Hybrid	YS Hybrid+85	15° (deg)	19°	23°	27°	31+°
		0.0"	0.5"	1.0"	1.5"	2.0"
	Tour AD UT 55, 65, 85, 95	Butt trim only				

### G-TECH

<b>WOOD</b>	<b>Driver</b>	<b>3W</b>	<b>4W</b>	<b>5W</b>	<b>7W</b>			
Tip Trimming - L or R Flex	0.0"	0.5"	1.0"	1.5"	1.5"			
<b>WOOD</b>	<b>Driver</b>	<b>3W</b>	<b>4W</b>	<b>5W</b>	<b>7W</b>			
Tip Trimming - A or S Flex	2.0"	2.5"	3.0"	3.5"	3.5"			
<b>IRON</b>	<b>3-IRON</b>	<b>4-IRON</b>	<b>5-IRON</b>	<b>6-IRON</b>	<b>7-IRON</b>	<b>8-IRON</b>	<b>9-IRON</b>	<b>PW</b>
Tip Trimming - L or R Flex	0.0"	0.5"	1.0"	1.5"	2.0"	2.5"	3.0"	3.0"
<b>IRON</b>	<b>3-IRON</b>	<b>4-IRON</b>	<b>5-IRON</b>	<b>6-IRON</b>	<b>7-IRON</b>	<b>8-IRON</b>	<b>9-IRON</b>	<b>PW</b>
Tip Trimming - A or S Flex	1.5"	2.0"	2.5"	3.0"	3.5"	4.0"	4.5"	4.5"